



Item No.	D	d	l	L	α	Stock	Stock	Stock
SL41	3	3	9.5	38	8°	●	●	
SL42	3	3	12.7	38	8°	●	●	
SL42 - L2	3	3	12.7	50	8°	○	○	
SL42 - L3	3	3	12.7	75	8°	○	○	
SL53	5	3	12.7	38	14°	○	●	
SL1	6	6	16	50	14°	●	○	
SL2	8	6	22	69	14°	●	○	
SL3	9.5	6	27	74	14°	●	○	○
SL4	12.7	6	28	76	14°	●	○	●
SL5	16	6	30	77	14°	●	○	○
SL7	19	6	38	85	14°	○	○	

MDC a richiesta · on request · auf Anfrage · sur demande · a petición · по запросу ● stock standard ○ non-standard stock ■ stock exhaustion



Always wear goggles when using the rotary burrs Per l'uso delle lime rotative è obbligatorio indossare occhiali protettivi
 Tragen Sie immer die Schutzbrille wenn Sie die Fräser benutzen Toujours porter les lunettes de sécurité en utilisant les limes rotatives
 Para usar las limas rotativas es obligatorio usar gafas de protección При работе с борфрезами всегда используйте защитные очки